



FSS ProClean CPVC **Mildly-Alkaline Cleaner Specifically Formulated for Cleaning** **CPVC Fire Suppression System Piping**

Huguenot Laboratories FSS ProClean CPVC is a concentrated blend of near neutral alkaline builders, particle soil dispersants, water conditioners, and a synergistic blend of detergents designed to provide effective penetration and removal of even the most stubborn oils, greases, tapping compounds, and shop soils in CPVC containing fire suppression piping.

FSS ProClean CPVC is also highly recommended for use on all ferrous metal and plastic combined systems.

Product Properties

Appearance:	Thick, clear, foamy liquid
Odor:	Very mild; Nil
Water Solubility:	Complete
Flash Point:	None
Amines:	None
Solvents:	None
Non-Ionic Surfactants:	None
pH (1%):	8.5-10.0
Biodegradability:	Detergent portion is 100% Biodegradable
HMIS Rating:	1, 0, 0

*The unique blend of soaps and alkali enables **FSS ProClean CPVC** to outperform many caustic and amine-based cleaners without fear of CPVC chemical attack.*

*100% of raw materials that compose **FSS ProClean CPVC** are listed as "Recommended for use in CPVC applications".*

Use Information

Cleaning and Flushing of CPVC Piping	0.5% to 2.0%
Temperature	Ambient
Contact Time	As Available

Precautions

May cause irritation to the eyes upon contact. Prolonged contact may cause skin irritation. ****AVOID CONTACT**** FOR INDUSTRIAL AND COMMERCIAL USE ONLY! Refer to MSDS for additional information.

Package

Bulk, Tote, 55, 30, 15, 5, and 4 X 1- Gallon Plastic Containers