



## FSS ProClean D3 Product Line Emulsifying Detergent for Cleaning Fire Suppression Systems

**Huguenot Laboratories FSS ProClean B Products** are a surface active formulation for maximum penetration and dispersion of oils and other hydrocarbons that can periodically contaminate commercial fire suppression systems and new piping installations. **FSS ProClean B Products** are used periodically when leaks or spills contaminate water systems or when cleaning grease and oil from piping.

**FSS ProClean B Products** improve the effectiveness of corrosion inhibitors by helping to provide cleaner heat transfer surfaces, thus enhancing inhibitor film formation.

### Product Properties

Appearance:	Clear Straw Yellow Liquid, Odor Nil
Specific Gravity:	1.12
Flash Point:	None
pH (0.2-0.5% BV):	7.0
Biodegradability:	100% Biodegradable By Present Standards
HMIS Rating:	0-1, 0, 0

**FSS ProClean B Products** are specifically formulated for use at a wide temperature range, and are low-foaming at room temperature and typical use concentrations.

### Use Information

Light Concentration	0.5% By Volume (1-Gallons per 1,000-Gallons)	
Heavy Concentration	1.0% By Volume (4-Gallons per 1,000-Gallons)	
Temperature	Ambient through 140 °F.	
Contact Time	Contact Time is best achieved after the system has been properly cleaned. A minimum of a 4 - hour soak time is recommended for dry or preaction fire systems. The addition of 2 - Gallons ( per 1,000-Gallons of system volume) of FSS BioGuard is recommended as a long term protection from bacterial infestation.	
Precautions	May cause irritation to the skin and eyes upon contact. <b>**AVOID CONTACT**</b> FOR INDUSTRIAL ANDCOMMERCIAL USE ONLY	
Weight	Bulk, 30 Gallon Plastic Containers- 227 lbs per 30 Gallon Drum	
Dimensions	Diameter – 19 ¼ inches	Height – 30 ¼ inches
Country of Origin	USA	